



| No. | ΠΕΡΙΓΡΑΦΗ                    | ΠΟΣ. |
|-----|------------------------------|------|
| 1   | Left motor cover             | 1    |
| 2   | Frame oil seal               | 1    |
| 3   | Bearing                      | 1    |
| 4   | Bearing housing              | 1    |
| 5   | O-ring                       | 1    |
| 6   | Bearing                      | 1    |
| 7   | Bolt                         | 1    |
| 8   | Pump body                    | 1    |
| 9   | Washer In/Out valve cap      | 6    |
| 10  | O-ring                       | 6    |
| 11  | Valve, Water Inlet/Outlet    | 6    |
| 12  | O-Ring                       | 6    |
| 13  | Water outlet joint           | 1    |
| 14  | O-Ring                       | 1    |
| 15  | Valve cap for the core       | 1    |
| 16  | Ball                         | 1    |
| 17  | Spring                       | 1    |
| 18  | Valve core                   | 1    |
| 19  | Gasket for piston            | 1    |
| 20  | Filter                       | 1    |
| 21  | O-Ring                       | 1    |
| 22  | Piston                       | 1    |
| 23  | Joint water inlet            | 1    |
| 24  | Spring                       | 1    |
| 25  | Handspike                    | 1    |
| 26  | O-Ring                       | 1    |
| 27  | O-Ring                       | 1    |
| 28  | core load release valve      | 1    |
| 29  | Pump Head                    | 1    |
| 30  | Screw Internal hexagonal     | 4    |
| 31  | top lance for the switch     | 1    |
| 32  | Connecting screw ring        | 1    |
| 33  | Down cover, pressure switch  | 1    |
| 34  | O-Ring                       | 1    |
| 35  | O-Ring                       | 1    |
| 36  | Screw connect                | 1    |
| 37  | Spring,                      | 1    |
| 38  | Elbow for pressure switch    | 1    |
| 39  | Pressure switch              | 1    |
| 40  | V-ring                       | 3    |
| 41  | O-ring                       | 3    |
| 42  | Interspace ringer            | 3    |
| 43  | O-ring                       | 3    |
| 44  | Interspace separating ringer | 3    |
| 45  | Reinforced seal              | 3    |
| 46  | Plunger & spring             | 1    |
| 47  | Plunger clip                 | 1    |
| 48  | motor                        | 1    |
| 49  | Orientation ring             | 8    |
| 50  | Self-acting screw            | 6    |

| No. | ΠΕΡΙΓΡΑΦΗ                         | ΠΟΣ. |
|-----|-----------------------------------|------|
| 51  | Right motor cover                 | 1    |
| 52  | Screw                             | 2    |
| 53  | Capacitor                         | 1    |
| 54  | Connection box                    | 1    |
| 55  | Self-acting screw                 | 4    |
| 56  | Switch                            | 1    |
| 57  | Switch cover                      | 1    |
| 58  | Grounding screw                   | 1    |
| 59  | Powercord jacket                  | 1    |
| 60  | Fr2900-upper handle, pp           | 1    |
| 61  | Sleeve plate of hose reel, pp     | 1    |
| 62  | Joint 1                           | 1    |
| 63  | Right cover of hose reel, pp      | 1    |
| 64  | Joint 2                           | 1    |
| 65  | Fr lance holder- right            | 1    |
| 66  | Fr lance holder- left             | 1    |
| 67  | Fr pressure gauge                 | 1    |
| 68  | Fastener for pressure gauge, q235 | 1    |
| 69  | Fr2900 front housing, pp          | 1    |
| 70  | Fr wheel circlip                  | 2    |
| 71  | Fr wheel shaft, q235              | 1    |
| 72  | End cap of fr wheel, pp           | 1    |
| 73  | Fr wheel hub, pp                  | 2    |
| 74  | Fr tire                           | 1    |
| 75  | Fr heel block                     | 1    |
| 76  | Fr back housing, pp               | 1    |
| 77  | Fr outlet sleeve, pp              | 1    |
| 78  | Fr detergent tank, pe             | 1    |
| 79  | Fr tire                           | 1    |
| 80  | End cap of fr wheel, pp           | 1    |
| 81  | Fr cable bracket, pp              | 1    |
| 82  | Screw cap, pp                     | 1    |
| 83  | Metel fastening piece, q235       | 2    |
| 84  | Fr lower handle, pp               | 1    |
| 85  | Left cover of hose reel           | 1    |
| 86  | Joint 3, pp                       | 1    |
| 87  | Handle 1 of hose reel, pp         | 1    |
| 88  | Spring                            | 1    |
| 89  | Handle 2 of hose reel, pp         | 1    |
| 90  | Hanle pin of hose reel,           | 1    |
| 91  | Tank cover, pp                    | 1    |
| 92  | Tank joint, pp                    | 1    |
| A   | Switch & cover(see No.56,57)      | 1    |
| B   | Wheel                             | 2    |
| C   | Handle                            | 1    |
| D   | Detergent pot                     | 1    |
| E   | Water inlet joint(See No.23)      | 1    |
| F   | Water outlet joint(see No.13)     | 1    |
| G   | Rotary Brush                      | 1    |
| H   | Spray gun                         | 1    |

