



No.	ΠΕΡΙΓΡΑΦΗ
1	Adjustment cover
2	Screw ST4×16
3	Adjusting knob
4	Dial
5	Connecting rod
6	Screw M6×10
7	Threaded rod
8	Front base
9	Capacitor
10	Switch
11	Soft handle cover
12	Inductor
13	Carbon brush cover
14	Screw ST4×16
15	Screw ST4×16
16	Cord clamp
17	Cord sleeve
18	Cord
20	Screw ST4×16
21	Back base
22	Stator
23	Screw ST4×55
24	Wind guide
25	Bearing 626Z
26	Brush holder

No.	ΠΕΡΙΓΡΑΦΗ
27	Copper bush holder
28	Carbon brush
29	Rotor
30	Bearing 608Z
31	Bearing press board
32	Screw ST4×8
33	Bearing 608Z
34	Blade holder
35	Bearing 6000Z
36	Bearing press board
37	Screw ST4×8
38	Housing
40	Screw ST4×20
41	Small belt wheel
42	Big belt wheel
43	M8 nut
44	Belt
45	Belt cover
46	Screw ST4×16
47	Lock knob
48	Supporting
49	Parallel guide
50	Wrench
51	Dust bag